

Shuffle Alley Maintenance & Inspection

We recommend once every two weeks to perform some simple maintenance to your shuffle Alley to insure proper operation of game play.

1. With POWER OFF, vacuum & clean Playboard. Players tend to get very generous when using the shuffle wax. For this very reason you want to clean any build up and clear the playboard so it looks well maintained. Failure to keep game cleanliness may hurt earnings. We recommend vacuuming all areas of the playboard, The shuffle wax is like a sand and tends to get everywhere. With the shuffle wax present it would make cleaning the playboard properly almost impossible. Once shuffle wax is removed and your surface is clear we recommend using Novus Plastic Polish #2 on the playboard. This will pick up almost all the scratches and help protect the playboard surface. It is also recommended you wipe the bottom of the puck with the plastic polish to remove any excess of wax build up that may cause the puck performance to diminish.

2. Open the coin door and pull out the interlock switch. Insert coins to verify proper operation of coin mechanisms.

3. Clean Monitor Plastic with a non abrasive towel and we recommend the use of Plastic Polish # 1 to wipe surface dust off and #2 to clean.


4. With a Philips screwdriver remove the two screws for the Shuffle Wax Catch Tray (located in pictorial below). Once removed pull out tray and dispose of any shuffle wax present in tray. Once cleaned out replace screws and mount door back to monitor cabinet.

5. Turn Power Back on. Open Coin door and go to Admin and Tests to check for proper operation of Switches and Pins. Check all Playboard Switches, see page pg 17 for tests instructions. Check start, select and slam tilt switches.

6. Play Pro Bowler to insure game plays satisfactory. Close Coin door and lock door.

If any problems occur or you simply have any questions on cleaning and maintenance call tech support.

Shuffle Wax Catch Tray →



Patrick Bohm